



NOTE:

1. DOUBLE THROW SWITCH SHOULD BE THE SAME SIZE AS THE SERVICE ENTRANCE.
2. IT TAKES A MINIMUM OF 2 H.P. TO DRIVE 1KW OF LOAD.

(EXAMPLE: A 25 KW GENERATOR WITH 25 KW OF LOAD ON IT WILL TAKE A MINIMUM OF 50 H.P. TO OPERATE THE GENERATOR PROPERLY).
3. NATIONAL ELECTRICAL CODE REQUIRES GENERATOR AND TRANSFER SWITCH BE GROUNDED.

DOUBLE THROW SWITCH INSTALL.		
M J M	AMICALOLA EMC	L R Y
MAY 1989	JASPER, GA.	